


HOME DECORATORS COLLECTION

BF-24934 OXFORD BUFFET 35"H×60"W×16"D

INV#08295













ASSEMBLY INSTRUCTIONS



















Made In China
















Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.



PARTS LIST		
A  TOP PANEL-1PC	B  BOTTOM PANEL-1PC	C  LEFT SIDE PANEL-1PC
D  RIGHT SIDE PANEL-1PC	E  STAND PANEL-1PC	F  LEFT ACROSS PANEL-1PC
G  RIGHT ACROSS PANEL-1PC	H  LEFT SHELVES-2PCS	I  RIGHT SHELVES-2PCS
J  UP ADORNING PANEL-1PC	K  BACK PANELS-2PCS	L  REAR PANEL GUIDE-1PC

M  DRAWER PANEL FRONTS-2PCS	N  LEFT DRAWER PANEL SIDES-2PCS	O  RIGHT DRAWER PANEL SIDES-2PCS
P  DRAWER PANEL BACKS-2PCS	Q  DRAWER SUOPPORT PANELS-2PCS	R  DRAWER PANEL BOTTOMS-2PCS
S  LEFT DOORS-2PCS	T  RIGHT DOORS-2PCS	U  FOOT-1PC
V  CAM-LOCKS-19PCS	W  CAM-BOLTS-19PCS	X 6mm× 1"  SCREWS-24PCS
Y 8mm× 5/8"  SCREWS-8PCS	Z  CAM-TOOL-1PC	A1  SHELF SUPPORTS-16PCS
B1 6mm× 3/8"  SCREWS-28PCS	C1  MAGNETS-2PCS	D1 7mm× 5/8"  SCREWS-38PCS

E1 5mm× 3/8"  SCREWS-12PCS	F1  FEMALE MAGNETS-4PCS	G1  KNOBS-8PCS
H1 5mm× 1/2"  SCREWS-40PCS	I1  HINGES-8PCS	J1  LEFT OUTER SLIDERS-2PCS
K1  LEFT INNER SLIDES-2PCS	L1  RIGHT OUTER SLIDERS-2PCS	M1  DOWELS-6PCS
N1  RIGHT INNER SLIDES-2PCS	O1 11mm× 1"  SCREWS-8PCS	P1  ALLEN WRENCH-1PC
Q1 6mm× 3/4"  SCREWS-3PCS		




NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

NOTE: • UPON OPENING, THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY, PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

HOW TO USE THE CAM-TOOL




NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS




1) . ASSEMBLE THE DRAWER.

- ATTACH DRAWER SIDE PANEL(N/O) USING 4 SCREWS(X) .
- ATTACH THE 2 KNOBS(G1) TO DRAWER PANEL FRONT(M) USING 2 SCREWS(Y) .
- INSERT THE DRAWER PANEL BOTTOM(R) INTO THE SLOTS IN THE DRAWER PANEL SIDES(N/O) .
- ATTACH DRAWER PANEL BACK(P) TO BETWEEN LEFT DRAWER PANEL SIDE(N) AND RIGHT DRAWER PANEL SIDE(O) USING 4 SCREWS(X) .
- ATTACH DRAWER SUPPORT PANELS(Q) TO DRAWER PANEL BOTTOM(R) USING 4 SCREWS(X) .




2) . ASSEMBLE THE INNER SLIDERS(K1/N1) .

- ATTACH THE INNER SLIDERS(K1/N1) TO DRAWER PANEL SIDE(N/O) USING 8 SCREWS(B1) .




3) . ASSEMBLE THE LEFT OUTER SLIDER(J1).

- ATTACH THE LEFT OUTER SLIDER(J1) TO LEFT SIDE PANEL(C) USING 3 SCREWS(B1).




4) . ASSEMBLE THE RIGHT OUTER SLIDER(L1).

- ATTACH THE RIGHT OUTER SLIDER(L1) TO RIGHT SIDE PANEL(D) USING 3 SCREWS(B1).




5) . ASSEMBLE THE LEFT OUTER SLIDERS(J1).

- ATTACH THE LEFT OUTER SLIDER(J1) TO STAND PANEL(E) USING 3 SCREWS(B1).




6) . ASSEMBLE THE RIGHT OUTER SLIDERS(L1).

- ATTACH THE RIGHT OUTER SLIDER(O1) TO STAND PANEL(E) USING 3 SCREWS(B1).




7) . ASSEMBLE THE UP ADORNING PANEL (J) .

- ROTATE THE 5 CAM-BOLTS(W) AND INSERT 4 DOWELS(M1) INTO THE HOLES IN THE UP ADORNING PANEL(J) .
- PLACE CAM-BOLTS(W) INTO THE HOLES IN THE BOTTOM PANEL(B) AND ATTACH USING 5 CAM-LOCKS(V) .




8) . ASSEMBLE THE MAGNETS(C1) .

- ATTACH THE 2 MAGNETS(C1) TO ACROSS PANEL(F/G) USING 4 SCREWS(D1) .




9) . ASSEMBLE THE LEFT ACROSS PANEL (F) .

- ATTACH THE LEFT ACROSS PANEL (F) TO STAND PANEL (E) USING 2 SCREWS (01) .




10) . ASSEMBLE THE RIGHT ACROSS PANEL (G) .

- ATTACH THE RIGHT ACROSS PANEL (G) TO STAND PANEL (E) USING 2 SCREWS (01) .




11) . ASSEMBLE THE BOTTOM PANEL (B) .

- ROTATE THE 2 CAM-BOLTS(W) INTO THE HOLES IN THE BOTTOM PANEL(B) .
- PLACE CAM-BOLTS(W) INTO THE HOLES IN THE STAND PANEL(E) AND ATTACH USING 2 CAM-LOCKS(V) .




12) . ASSEMBLE THE BOTTOM PANEL (B) .

- ROTATE THE 3 CAM-BOLTS(W) AND INSERT DOWEL(M1) INTO THE HOLES IN THE RIGHT SIDE PANEL(D) .
- PLACE CAM-BOLTS(W) INTO THE HOLES IN THE PANEL(B/J) AND ATTACH USING 3 CAM-LOCKS(V) .
- ATTACH THE RIGHT ACROSS PANEL(G) TO RIGHT SIDE PANEL(D) USING 2 SCREWS(O1) .




13) . ASSEMBLE THE BOTTOM PANEL (B) .

- ROTATE THE 3 CAM-BOLTS(W) AND INSERT DOWEL(M1) INTO THE HOLES IN THE LEFT SIDE PANEL (C) .
- PLACE CAM-BOLTS(W) INTO THE HOLES IN THE PANEL (B/J) AND ATTACH USING 3 CAM-LOCKS (V) .
- ATTACH THE LEFT ACROSS PANEL (F) TO LEFT SIDE PANEL (C) USING 2 SCREWS (O1) .




14) . ASSEMBLE THE TOP PANEL (A) .

- ROTATE THE 6 CAM-BOLTS(W) INTO THE HOLES IN THE TOP PANEL (A) .
- PLACE CAM-BOLTS(W) INTO THE HOLES IN THE PANEL (C/D/E) AND ATTACH USING 6 CAM-LOCKS (V) .




15) . ASSEMBLE THE FOOT(U) .

- ROTATE THE FOOT(U) INTO THE HOLE IN THE BOTTOM PANEL(B) .




16) . ASSEMBLE THE DOORS(R/S) .

- ATTACH THE 2 KNOBS(G1) TO DOORS(S/T) USING 2 SCREWS(Y) .
- ATTACH THE 2 FEMALE MAGNETYS(F1) TO DOORS(S/T) USING 2 SCREWS(H1) .
- ATTACH THE 4 HINGES(I1) TO DOORS(S/T) USING 12 SCREWS(H1) .




17) . ASSEMBLE THE LEFT DOORS(S) .

- ATTACH THE LEFT DOORS(S) TO PANEL(C/E) USING 6 SCREWS(H1) AND 6 SCREWS(E1) .




18) . ASSEMBLE THE RIGHT DOORS(T) .

- ATTACH THE RIGHT DOORS(T) TO PANEL(D/E) USING 6 SCREWS(H1) AND 6 SCREWS(E1) .




19) . ASSEMBLE THE SHELF SUPPORTS(A1) .

- INSERT 16 SHELF SUPPORTS(A1) INTO THE HOLES IN THE PANEL(C/D/E) .




20) . ASSEMBLE THE LEFT SHELVES(H) .

- PLACE THE LEFT SHELVES(H) ONTO THE SHELF SUPPORTS(A1) .




21) .ASSEMBLE THE RIGHT SHELVES(I) .

- PLACE THE RIGHT SHELVES(I) ONTO THE SHELF SUPPORTS(A1) .



22) .ASSEMBLE THE DRAWERS .

- SLIDE THE DRAWERS INTO SLIDERS .



23) . ASSEMBLE THE BACK PANELS(K) .

- INSERT THE BACK PANELS(K) INTO THE SLOT IN THE REAR PANEL GUIDE(L) .
- ATTACH THE BACK PANELS(K) AND REAR PANEL GUIDE(L) USING SCREWS(D1/Q1) .